

OWNERS MANUAL

All 3 Section Hinged Christmas Trees




LITTLE GROVE
MORE THAN A TREE

Before beginning

- Check whether all parts have been delivered
- Save the carton box for storing your tree.
- All the diagrams are given for illustrative purpose only. There may be variations from one model to another.


Content:

Article No.	Height	Number of tree parts	Base
XMTSS00180	180 cm	3	Metal
XMTSS00210	210 cm	3	Metal
XMTGS00180	180 cm	3	Metal
XMTGS00210	210 cm	3	Metal
XMTGS00210S	210 cm	3	Metal
XMTGS00240S	240 cm	3	Metal
XMTWS00180	180 cm	3	Metal
XMTWS00210	210 cm	3	Metal



Assembly instructions

1. Remove the tree stand and adjust the legs to form an X shape and loosely insert one of the thumb screws to secure the legs in place. Your assembled tree may be heavy and difficult to move, so place the stand in the desired location before assembling.
2. Remove the temporary plastic covers from the end of the pole sections with branches.
3. Place the tree section with the highest letter value (also the only section with a pointed end on the bottom of the pole) into the stand. Tighten the thumb screw on the stand.
4. Allow the branches to fall into place. This may require gently pulling them outward & downward as branches can get tangled during shipping.
5. Starting with the bottom row, open the leaves or tips of the branches by separating them into different directions. Start with the tips closest to the pole and work your way outward alternating the tips left, right and center.
6. Gently curve the branch tips upward to provide a more realistic and uniform appearance.
7. Some branches may have wings or side branches. Wing branches should be pulled horizontally away from the main branch and pointed forward at a 45 degree angle.
8. When each section is complete, step back and look at your work. Cover any gaps by shifting branch tips to fill them.
9. Set the next highest lettered section with branches into the bottom section and follow the same steps as above. Continue this process until you reach the top.
10. Tighten all thumb screws.



Disassembly and storage

- Remove all decorations.
- Disassemble the tree in reverse order of the assembly.
- For a better conservation, store the tree in its carton box in a cool dry place. Do not store when humid.

Caution

- To be assembled by or under supervision of an adult.
- Keep plastic bags out of reach of young children.
- Keep away from fire or hot temperature. Do not light a candle on or near the tree. Do not leave lighted lighting chains unattended.
- Do not overload the tree with heavy and/or too numerous decorations.
- Place the tree on a plane surface in order to ensure its stability.
- This tree is intended for indoor use only
- Keep an eye on young children.
- Keep those information for future reference.